

#1620 イーグルタイヤウォーマー3

この度はイーグルタイヤウォーマー3をお買い求め頂き、誠にありがとうございます。

本品はタイヤサイズを選ばないベルト方式を採用し、タイヤへの脱着性と熱伝導性が大幅に向上しました。本品を用い、走行前にタイヤをウォームアップさせることで、外気温を問わず安定したグリップを確保し、ラップタイムを向上させることができます。また、通電性の高い7.2Vゴールドコネクターを用い、満充電のRC3000バッテリーならば80℃で55分以上の連続使用が可能です。

使用上の注意

- ◎タイヤ、ホイールの材質、路面状況により、低温でのウォームアップがベストな場合もあります。(テスト走行等を行い、ウォームアップ時間を調節してください)
- ◎本品は1/10EPツーリングカー専用です。タイヤ径の大きなものにはご使用になれません。
- ◎バッテリーを接続している時はその場を離れず、常に監視しながら作業を行ってください。(異常を感じた場合はバッテリーを外し、速やかに作業を中止してください。)
- ◎紙などの燃えやすいものから遠ざけてご使用ください。
- ◎ウォーマーは雨や水滴などを嫌います。水濡れを避けてお使いください。
- ◎指定電圧以上の電源使用は行わないでください。(本品工場出荷時には7.2V入力で80℃に設定されています。それ以外の電圧でのご使用は大変危険です。)
- ◎小さなお子様の手の届かない場所でご使用、保管してください。
- ◎本品に改造を加えないでください。

接続方法

1. タイヤの表面にグリップ剤等を使用している場合はよく拭き取ってください。
 2. それぞれのタイヤにウォーマーを装着し、7.2Vバッテリーを接続します。
 3. 約15秒程でヒーターが80℃くらいまで上昇します。約3分程ウォームアップしてください。
* 上記のウォームアップ時間は目安です。タイヤ、ホイールの材質、路面状況により、低温でのウォームアップがベストな場合もありますのでテスト走行等を行い、ウォームアップ時間を調節すると良いでしょう。(ユニット本体は連続使用しても問題はありません)
 4. ウォーマーが十分温まったらコネクターを外します。
 5. ヒーターベルトが余熱で温め続けます。
 6. スタート寸前にウォーマーを外し走行してください。
ウォームアップされたタイヤは走行直後より十分にグリップを発揮します。
- ★その他、ご不明な点等がございましたらイーグルサービスカウンターまでご相談ください。

株式会社イーグル模型

愛知県豊橋市岩屋町62-79

TEL 0532-61-1554 FAX 0532-61-1727

E-mail: service11@eaglemodel.com

HP: www.eaglemodel.com

Tire warmer 3

This TIRE WARMER3 gives a tire high traction at any temperature. You'll see the difference in driving condition. Use it before driving a car.

We put the heater belt fits for 1/10 tire. Our own design makes heat spreaded equally to a tire and easily can fit and take off any 1/10 tire in the market.

TIRE WARMER3 for 1/10 Touring car 4pcs warmer, just connect all in one connector to 7.2V battery. If you use RC3000 6cells, warmer will be heat up to 80℃(190° F). For approximately 55 min.

CAUTION;

- ◎Choose low heat if it's necessary. Depends on the material of tire and wheel.
- ◎Do not use for other purposes. This is only for 1/10 EP touring car.
- ◎Do not leave when it is used. Avoid flammable staff.
- ◎Avoid water and moisture.
- ◎Never allow other foreign materials to warmers.

How to use

1. Wipe off a traction oil before use.
2. Cover up tires with a tire warmer3, then connect to 7.2V battery.
3. Warm up for 3 minutes after it is warmed up to 80 degree. Adjust the time depending on the material of tire and wheel.
4. Take off a connector.
5. Keeps heating by remaining heat.
6. Take off a warmer before driving a car.